



# Owner's Manual

## ADDENDUM

**If the pillow illustrated below is located on your spa then use the following instructions on how to remove and replace your spa pillow.**

### **REMOVE:**

Carefully pull and lift on one end of pillow to stretch pillow (longer) until the pillow is released from the plastic retainer. Once one end is released, push pillow in opposite directions to remove from other retainer.

### **REPLACE:**

With the arrow located on back side of the pillow pointing upwards, slide one end of pillow onto the spa retainer. Pull other end of pillow; using both hands lift pillow above retainer and with a stretching motion slide pillow recess onto retainer.

